

CONNECTED CHEF ™

KITCHEN TABLET + FOOD PREP STATION



USER GUIDE

INDEX

SETTING UP

Battery

Power

Lock Screen

Connect to WiFi

PERSONALIZATION

Language

Time

Screen Timeout

Screen Brightness

Screen Orientation

USING YOUR CONNECTED CHEF™


Home Screen

Apps


Bluetooth

Set Alarms and Timers

Cleaning



BUTTONS ARE LOCATED ON THE DISPLAY END
OF THE CONNECTED CHEF™



USB-C PORT

POWER


VOLUME DOWN

VOLUME UP


MICROPHONE

HOW TO CHARGE THE BATTERY

Connect the USB-C cable to the USB-C port on the side of
the Connected Chef™



110V / 5V 2A POWER ADAPTER



2M USB-C CABLE




POWER



POWER

TURN ON

Press the power button on the side of the Connected Chef™ board.
Start-up takes approximately 60 seconds.



SLEEP MODE

Press the power button again on the side of the Connected Chef™ board to put the display in sleep mode


POWER OFF / RESTART

Press and hold the power button on the side of the Connected Chef™ board for 5 seconds

Option buttons will appear on the screen



Power Off



Restart


LOCK SCREEN




When the Connected Chef™ starts up, the lock screen is displayed

UNLOCK

To unlock, swipe up from the bottom of the screen




HOME SCREEN




When the Connected Chef™ is active, the Home Screen will be displayed

CONNECT WIFI




OPEN NOTIFICATION PANEL TO VIEW WIFI

Swipe down from the top of the screen
to display the Notification Panel



TURN ON/OFF WIFI


Tap the internet button



CONNECT / PAIR WIFI



Press and Hold the internet
button Enter Wifi connection
settings





SYSTEM SETTINGS

LANGUAGE



HOW TO ADD A LANGUAGE


From the home screen, swipe up from the bottom of the screen

Click the Settings icon to launch Settings

Tap System



Select Languages and Input

Select Language



SYSTEM SETTINGS

TIME



HOW TO CHANGE TIME


From the home screen, swipe up from the bottom of the screen

Click the Settings icon to launch Settings

Tap System



Select Date & Time

Adjust Time



SYSTEM SETTINGS

SCREEN TIMEOUT



HOW TO CHANGE SCREEN TIMEOUT

From the home screen, swipe up from the bottom of the screen


Click the Settings icon to launch Settings

Tap Display


Select Screen timeout

Select Timeout Duration from list

SCREEN BRIGHTNESS




ADJUST SCREEN BRIGHTNESS




Swipe down twice from the top of the screen
to display the full Notification Panel

The display brightness controller will appear

Slide the brightness controller to adjust screen brightness




ROTATE DISPLAY





OPEN NOTIFICATION PANEL TO VIEW SCREEN ROTATION BUTTON

Swipe down from the top of the screen
to display the Notification Panel





TURN ON SCREEN ROTATION

Tap the Screen Rotation
button



ROTATE DISPLAY





Rotate the Connected Chef to the desired orientation



Lift the Connected Chef vertically to make the display rotate

TURN OFF SCREEN ROTATION

Tap the Screen Rotation button




HOME SCREEN BUTTONS



BACK

Go back to the previous screen on your browser or app



HOME

Display the home screen



VIEW OPEN APPS/BROWSER

View content running in the background

ANDROID 13 GO



Assistant



Calculator



Calendar



Chrome



Clock



Contacts



Drive



Files



Gallery



Gmail



Google



Google TV



Kids Space



Maps



Meet



Play Books



Play Store



Settings



SoundRec...



YouTube




YT Kids




YT Music

**LEARN MORE ABOUT
ANDROID 13 GO**

**ANDROID 13 GO
USER HELP**





APPS



From the home screen, swipe up from the bottom of the screen

VIEW APPS

You will now see all the installed Apps on the Connected Chef™ board



HOW TO INSTALL APPS

Click Play Store icon to launch the app
This is the official app store

HOW TO DELETE/UNINSTALL AN APP



Slide up on the home screen to display all installed apps


Press and hold on the app you want to uninstall

Hold and slide to the top of the screen

A uninstall 'trash can' icon will appear

Slide the app over the 'trash can' icon and the app will be uninstalled from the Connected Chef™ board





VIEW OPEN APPS


HOW TO SELECT AN OPEN APP TO USE

Press the 'View Open Apps' button on the home screen
Slide right to left to scroll through the list of open apps
Tap on the screen image of the apps you want to use




HOW TO CLOSE AN APP THAT IS RUNNING IN THE BACKGROUND

Press the 'View Open Apps' button on the home screen
Slide right to left to scroll through the list of open apps
Press and hold on the screen image of the app you want to close
Hold and slide up to the top of the screen
This will close/exit the app




BLUETOOTH





OPEN NOTIFICATION PANEL TO VIEW BLUETOOTH BUTTON

Swipe down from the top of the screen
to display the Notification Panel




TURN ON/OFF BLUETOOTH

Tap the
Bluetooth button



CONNECT / PAIR BLUETOOTH

Press and Hold the
Bluetooth button
Select Pair New Device



ALARMS AND TIMERS




HOW TO SET TIMERS AND ALARMS

From the home screen, swipe up from the bottom of the screen

Click the clock icon to launch


HOW TO SET AN ALARM

Tap the Alarm icon
Type the Alarm time



HOW TO SET A TIMER


Tap the Timer icon
Type the Timer duration



CLEANING



HOW TO CLEAN THE DISPLAY




Wipe with a damp cloth

Do not submerge in water

Not dishwasher safe

HOW TO CLEAN THE CUTTING BOARD


Slide out the cutting board from the Connected Chef™ base



Hand Wash

Not dishwasher safe

SCAN FOR



MORE INFO



CONNECTED-CHEF.COM